



# Source Water Assessment Program (SWAP) Report For Pine Hill Condominiums

## What is SWAP?

The Source Water Assessment Program (SWAP), established under the federal Safe Drinking Water Act, requires every state to:

- ? Inventory land uses within the recharge areas of all public water supply sources;
- ? Assess the susceptibility of drinking water sources to contamination from these land uses; and
- ? Publicize the results to provide support for improved protection.

## SWAP and Water Quality

Susceptibility of a drinking water source does *not* imply poor water quality. Actual water quality is best reflected by the results of regular water tests.

Water suppliers protect drinking water by monitoring for more than 100 chemicals, treating water supplies, and using source protection measures to ensure that safe water is delivered to the tap.

Prepared by the  
Massachusetts Department of  
Environmental Protection,  
Bureau of Resource Protection,  
Drinking Water Program

Date Prepared:  
November 16, 2002

**Table 1: Public Water System (PWS) Information**

<b>PWS NAME</b>	Pine Hill Condominiums
<b>PWS Address</b>	205 & 209 Great Road
<b>City/Town</b>	Acton, Massachusetts 01720
<b>PWS ID Number</b>	2002010
<b>Local Contact</b>	Deborah Bray
<b>Phone Number</b>	(978)486-1008

<b>Well Name</b>	<b>Source ID#</b>	<b>Zone I (in feet)</b>	<b>IWPA (in feet)</b>	<b>Source Susceptibility</b>
Well #1	2002010-01G	223	546	Moderate

## Introduction

We are all concerned about the quality of the water we drink. Drinking water wells may be threatened by many potential sources of contamination, including septic systems, road salting, and improper disposal of hazardous materials. Citizens and local officials can work together to better protect these drinking water sources.

### Purpose of this report:

This report is a planning tool to support local and state efforts to improve water supply protection. By identifying land uses within water supply protection areas that may be potential sources of contamination the assessment helps focus protection efforts on appropriate best management practices (BMPs) and drinking water source protection measures. Department of Environmental Protection (DEP) staff are available to provide information about funding and other resources that may be available to your community.

### This report includes:

1. Description of the Water System
2. Discussion of Land Uses within Protection Areas
3. Recommendations for Protection
4. Attachments, including a Map of the Protection Areas

## 1. Description of the Water System

Pine Hill Condominium obtains its water supply from a bedrock well located on the complex grounds. The bedrock well is 353 foot deep with a Zone I of 223 feet and an Interim Wellhead Protection Area (IWPA) of 546 feet. The IWPA provides an interim protection area for a water supply well when the actual recharge area has not been delineated. The actual recharge area to the well may be significantly larger or smaller than the IWPA. The well is located in an aquifer with a high vulnerability to contamination due to the absence of hydrogeologic barriers that can prevent contaminant migration. Please refer to the attached map of the Zone I and IWPA. The well serving the facility has no treatment at this time. For current information on monitoring results and treatment, and a copy of the most recent Consumer Confidence Report, please contact the

### What is a Protection Area?

A well's water supply protection area is the land around the well where protection activities should be focused. Each well has a Zone I protective radius and an Interim Wellhead Protection Area (IWPA).

- **The Zone I** is the area that should be owned or controlled by the water supplier and limited to water supply activities.
- **The IWPA** is the larger area that is likely to contribute water to the well.

In many instances the IWPA does not include the entire land area that could contribute water to the well. Therefore, the well may be susceptible to contamination from activities outside of the IWPA that are not identified in this report.

### What is Susceptibility?

Susceptibility is a measure of a well's potential to become contaminated due to land uses and activities within the Zone I and Interim Wellhead Protection Area (IWPA).

Public Water System contact person listed above in Table 1. Drinking water monitoring reporting data is also available on the web via EPA's Envirofacts website at [http://www.epa.gov/enviro/html/sdwis/sdwis\\_query.html](http://www.epa.gov/enviro/html/sdwis/sdwis_query.html).

## 2. Discussion of Land Uses in the Protection Areas

There are a number of land uses and activities within the drinking water supply protection areas that are potential sources of contamination.

#### Key issues include:

1. **Inappropriate Activities in Zone I;**
2. **Landscaping and Lawncare**
3. **Septic systems; and**
4. **Transportation corridor**

The overall ranking of susceptibility to contamination for the well is Moderate, based on the presence of only moderate and low threat land use or activity in the IWPA, as seen in Table 2.

1. **I – Zone** Currently, the well does not meet DEP's restrictions, which only allow water supply related activities in Zone Is. The facility's Zone I contains buildings, athletic fields, roads, and parking areas. The public water supplier does not own and/or control all land encompassed by the Zone I. Please note that systems not meeting DEP Zone I requirements must get DEP approval and address Zone I issues prior to increasing water use or modifying systems.

#### Recommendations:

- V Remove all non-water supply activities from the Zone I to comply with DEP's Zone I requirements.
- V Do not use or store pesticides, fertilizers or road salt within the Zone I.

2. **Landscaping and lawn care** - Fertilizer is applied to the lawn that is located within the Zone I and IWPA. Fertilizers and pesticides, if improperly applied or stored, can be potential sources of contamination to the water supply.

#### Recommendations:

- V Do not use fertilizers or pesticides in the Zone I.

**Table 2: Table of Activities within the Water Supply Protection Areas**

Potential Contaminant Sources	Zone I	IWPA	Threat	Comments
Parking lot, driveways & roads	Yes	Yes	Moderate	Limit road salt usage and provide drainage away from wells
Landscaping & Lawncare	Yes	Yes	Moderate	Fertilizer & pesticide use.
Septic System	No	Yes	Moderate	See septic systems brochure in the appendix
Transportation corridor	No	Yes	Moderate	Route 2A.
Structures	Yes	Yes	-	Non-water supply structures in Zone I

\* -For more information on Contaminants of Concern associated with individual facility types and land uses please see the SWAP Draft Land Use / Associated Contaminants Matrix on DEP's website - [www.state.ma.us/dep/brp/dws/](http://www.state.ma.us/dep/brp/dws/).

## Glossary

**Zone I:** The area closest to a well; a 100 to 400 foot radius proportional to the well's pumping rate. To determine your Zone I radius, refer to the attached map.

**IWPA:** A 400 foot to ½ mile radius around a public water supply well proportional to its pumping rate; the area DEP recommends for protection in the absence of a defined Zone I I. To determine IWPA radius, refer to the attached map.

**Zone II:** The primary recharge area defined by a hydrogeologic study.

**Aquifer:** An underground water-bearing layer of permeable material that will yield water in a usable quantity to a well.

**Hydrogeologic Barrier:** An underground layer of impermeable material that resists penetration by water.

**Recharge Area:** The surface area that contributes water to a well.

- ✓ Use best management practices when applying fertilizer in the IWPA.

3. **Septic system** – The septic system is located within the IWPA of the water supply. If a septic system fails or is not properly maintained it could be a potential source of microbial and nitrate contamination. Improper disposal of household hazardous chemicals to septic system is a potential source of contamination to the water supply.

### Recommendations:

- ✓ Residents should be instructed on the proper disposal of spent household chemicals. Include custodial staff, groundskeepers, and certified operator.
- ✓ Septic system components should be located, inspected, and maintained on a regular basis.

4. **Transportation corridor** - Route 2A is located within the IWPA of the water supply. Route 2A is one of the main roads through the town, which increases the chances of contamination from accidents or spills and road salt.

### Recommendations:

- ✓ Contact your local fire department to ensure that the IWPA is included in emergency response planning.
- ✓ Regarding salt use, work with your local highway supervisor to encourage reducing road salt use in your IWPA.

Implementing the following recommendations will reduce the system's susceptibility to contamination.

## 3. Protection Recommendations

Implementing protection measures and best management practices (BMPs) will reduce the well's susceptibility to contamination.




Figure 1: Example of how a well could become contaminated by different land uses and activities.

### Zone I:

- ✓ Keep non-water supply activities out of the Zone I.
- ✓ Consider well relocation if Zone I threats cannot be mitigated.
- ✓ Since the Association intends to continue using the structures in the Zone I, use BMPs and restrict activities that could pose a threat to the water supply.
- ✓ Do not use pesticides or fertilizers within the Zone I.

### Training and Education:

- ✓ Instruct residents on proper hazardous material use, disposal, emergency response, and best management practices; include custodial staff, groundskeepers, and certified operator. Post labels as appropriate on raw materials and hazardous waste.
- ✓ Post drinking water protection area signs at key visibility locations.

### For More Information:

Contact **Josephine Yemoh-Ndi** in DEP's **Worcester Office** at **(508) 792-7650 x4030** for more information and for assistance in improving current protection measures.

More information relating to drinking water and source protection is available on the Drinking Water Program web site at:

[www.state.ma.us/dep/brp/dws/](http://www.state.ma.us/dep/brp/dws/)

### Additional Documents:

To help with source protection efforts, more information is available by request or online at [www.state.ma.us/dep/brp/dws/](http://www.state.ma.us/dep/brp/dws/), including:

1. Water Supply Protection Guidance Materials such as model regulations, Best Management Practice information, and general water supply protection information.
2. MA DEP SWAP Strategy
3. Land Use Pollution Potential Matrix
4. Draft Land/Associated Contaminants Matrix

Copies of this assessment have been provided to the public water supplier and town boards.

### Facilities Management:

- ✓ Implement standard operating procedures regarding proper storage, use and disposal of hazardous materials. To learn more, see the hazardous materials guidance manual at [www.state.ma.us/dep/bwp/dhm/dhmpubs.html](http://www.state.ma.us/dep/bwp/dhm/dhmpubs.html).
- ✓ Eliminate non-sanitary wastewater discharges to on-site septic systems. Instead, in areas using hazardous materials, discharge drains to a tight tank or sanitary sewer.
- ✓ Implement Best Management Practices (BMPs) for the use of fertilizer, herbicides and pesticides on facility property.

### Planning:

- ✓ Work with local officials in Acton to include the Pine Hill Condominium IWPA in Aquifer Protection District Bylaws and to assist you in improving protection.
- ✓ Have a plan to address short-term water shortages and long-term water demands. Keep the phone number of a bottled water company readily available.
- ✓ Supplement the SWAP assessment with additional local information and incorporate it into water supply educational efforts. Use a land use inventory to assist in setting priorities, focusing inspections, and creating educational activities.

### Funding:

The Department's Wellhead Protection Grant Program provides funds to assist public water suppliers in addressing Wellhead protection through local projects. Protection recommendations discussed in this document may be eligible for funding under the "Wellhead Protection Grant Program". For additional information, please refer to the attached program fact sheet. Please note: each program year the Department posts a new Request for Response for the Grant program (RFR). Other funding opportunities are described in "Grant and Loan Programs: Opportunities for Watershed Protection, Planning and Implementation" at <http://www.state.ma.us/dep/brp/mf/files/glprgm.pdf>.

These recommendations are only part of your ongoing local drinking water source protection. Citizens and community officials should use this SWAP report to spur discussion of local drinking water protection measures.

## 4. Attachments

- Map of the Public Water Supply (PWS) Protection Area.
- Recommended Source Protection Measures Factsheet
- Your Septic System Brochure
- Pesticide Use Factsheet
- Wellhead Protection Grant Program Fact Sheet
- Source Protection Sign Order Form